

Encorp recycling bin lid assembly instructions



1

Remove tape on each side beginning with the two ends as shown.



5

Remove the tape from the side flaps.



2

Bend inside flaps aligning with the inside edge of the groove.



6

Bend side flaps towards the middle of the box top.



3

Bend the flap towards the inside of the box top.



7

Press the side flaps carefully and repeat at the other edge of the box top.



4

Press the flap carefully to make contact with the side of the flap all the way to the corners. Then repeat at the opposite side.



8

Completed assembly.